




41-001

CHROME SHOWER HOOP AND RISER KIT TROUSSE DE CERCEAU DE DOUCHE ET CONDUITE ASCENDANTE CHROMÉES


□ 41-001




ILLUSTRATED PARTS LIST | LISTE DE PIÈCES ILLUSTRÉE




1 |
PB-4100107-COULPINGC
COUPLING CONNECTOR
CONNCTEUR DE COUPLAGE




2 |
PB-4100114-ESCUTCHN
ESCUTCHEON FLANGE
REBORD ESCUTCHEON



3 |
PB-41001-PART C
SUPPORT TEE
TEE DE SOUTIEN




4 |
PB-41001-PART GHI
HARDWARE
MATÉRIEL




5 |
PB-41001-PART K
RISER TUBE
TUBE RISER




6 |
PB-41001-PART N
RISER TUBE
TUBE RISER




7 |
PB-4100108-SHWR TUBE
SHOWER TUBE
TUBE DE DOUCHE



8 |
PB-41001-PART A
CEILING SUPPORT
SUPPORT DE PLAFOND



9 |
PB-41001-PART E
SUPPORT ROD
TIGE DE SUPPORT



10 |
PB-41001-PART J
SUPPORT ROD
TIGE DE SUPPORT